

EMG Spike Decomposition

Shakthi Visagan

804 622 954

M260

Liu

Introduction

- Contracting muscles are evidence of neuromuscular activity
- We can use electromyography (EMG) to measure the and record these signals
- Several electrodes will record the firing of action potentials or motor unit action potentials (MUAPs) and then amplify the signal using filters and amplifiers
- Identifying the specific neurons that fired the spikes will lead to better diagnoses of neuromuscular diseases, and may even contribute to the theory of neuroscience, as evidenced by the discovery of the Rosehip Neuron, where spike sorting played a critical role in identifying the unique Rosehip spikes

Problem


**DETECT, SEPARATE, IDENTIFY SEPARATE
SPIKES ACCORDING TO THE NEURONS
THAT MAY HAVE FIRED THE RESPECTIVE
ACTION POTENTIAL.**

Workflow

1. Administrative Code
2. Input File
3. Filtering the Signal by Removing Frequencies
4. Detecting Spikes
5. Aligning Spikes
6. t-SNE Latent Space Measurements (Preliminary feature extraction/clustering)
7. PCA Dimensionality Reduction & Feature Extraction
8. Initial k -Means Clustering
9. Final k -Means Clustering & Analysis

Administrative Code & Input File


- Most important to establish in this step are the frequencies of the signal
 - Sampling frequency \rightarrow `freq_samp`
 - Nyquist frequency \rightarrow `freq_samp/2` \rightarrow `freq_Nyquist`



Filtering the Signal by Removing Frequencies


- Perform a Fourier Analysis
 - Requires that we shift our signal by its mean
 - Take the FFT (Fast Fourier Transform) of the signal to identify the frequency components
 - Evaluate the *power* of the signal
- Problems
 - Our signal is nonstationary (the underlying distribution and the parameters of the signal changes with time)
 - Highly nonlinear signal
 - Better to have used empirical mode decomposition, Hilbert Huang Transform, or wavelet decomposition

Power Spectrum of Mean Centered Signal




Filtering the Signal by Removing Frequencies

- Use Butterworth *bandpass* filter (more of a *lowpass* filter)
 - `freq_lowerCutOff = 250; % [Hz]`
 - `freq_upperCutOff = 800; % [Hz]`
 - `[b,a] =`
 - `butter(4, [freq_lowerCutOff/(freq_Nyquist), freq_upperCutOff/(freq_Nyquist)], 'bandpass');`
 - `filt_sig = filtfilt(b, a, test_input);`
- We can evaluate the performance by recalculating the FFT
- We can also compare it to the original signal
 - We see that the signal loses some amplitude after removing some of the noisy lower frequencies
- More could be done if signal was sampled at a higher rate




Filtered EMG Signal




Detecting Spikes

- % Quiroga et. al threshold
 - `std_dev_estimate = median(abs(filt_sig)/0.6745);`
 - `MPH_Thr = 6*std_dev_estimate;`
 - `MPD = 5e-3;` % width of a usual pulse or the minimum peak spread [seconds]
- We can define an estimate of the noise based on the median absolute amplitude of the filtered signal
- Then use `findpeaks` to find the peaks and the indices of the signal based on the noise estimate
- We can plot the peaks using a binary *Dirac* impulse at the found locations of the signal to contain spikes

Spike Detected EMG Signal




Spike Detected EMG Signal



Aligning Spikes

- Need a buffer region around the peaks to obtain the area of the spikes
- Can use *cubic spline interpolation*
 - We want 100 points around the peak to determine the “spike”
 - Sample originally 400 points around the peak
 - Align by the max peak in that spike region
 - Take the cubic spline interpolation of 100 points in the same region
- Problems
 - Issues arise when peaks are at the beginning or the end of the signal due to large window sizes
 - Peaks are not always aligned by max amplitude since sampling more points might alias higher amplitude points


Spike Detected w/ Buffer Region and Cubic Spline Interpolation EMG Signal




t-Distributed Stochastic Neighbor Embedding

- PCA requires a number of components to keep in the model after selection running
- t-SNE is an unsupervised dimensionality reduction technique and it helps visualize high dimensional datasets
 - In particular, the space it chooses has little meaning
 - However, if two objects are close to each other (in terms of a distance metric, in this case *cosine* distance, or the *correlation*) then they are similar
 - Objects that are dissimilar will be farther apart
 - Axes have no meaning
 - We choose to embed the collection in a 3D space and present multiple views, the final view suggests that bifurcating the dataset is possible (by visual inspection)


3-D Embedding t-SNE for Spikes



3-D Embedding t-SNE for Spikes




3-D Embedding t-SNE for Spikes




PCA & Feature Extraction

- Knowing that two clusters can possibly be easily *shattered* (in terms of VC dimension) gives me confidence that the noisy dataset can be reduced
 - `[coeff,score,latent,~,explained] = pca(detected_spikes_holder);`
 - `pca_score_holder = score(:,1:3);`
 - We present multiple views to highlight the similarity between t-SNE and PCA
- Percent variance explained by the first three components is not high.
 - At best, the first three principal components explain about 10% of the variance
 - This is worrying and remarkably low

PCA Dimensionality Reduction of Spikes




PCA Dimensionality Reduction of Spikes




Cluster Spikes: k-Means Clustering

- We can cluster our PCA reduced dataset into two obvious classes.
- Doing so will remove even more noise, and then we can again cluster on one of the remaining datasets.
- Instead of plotting the PC reduced dataset clustered, I replot the spikes clustered by their respective class
- Doing so, and plotting their means tells us about the nature of the spikes stored in the class
- We believe that the two clusters represent spikes that were $-,+,-$, in magnitude for one, and $+,-,+$ for the other

Initial Cluster Assignments




Centroids of initial k-Means




Classify Spikes & Analysis

- We then classify the spikes in the larger first cluster
- We use the *elbow* method of determining the right number of clusters
 - Cannot use t-SNE here since t-SNE cannot separate or shatter this space that well
 - Elbow method works similarly to checking whether or not the percent variance explained is greater than some cut off
 - The percent variance increases as the number of clusters increases
 - By doing so we can identify individual spike shapes
 - To increase the robustness of spike identification due to the low sampling rate, we also employ cubic spline interpolation, which gives rise to the smooth spike shapes


Sorted Spikes in Cluster 1




Final Cluster Assignments




Final Cluster Assignments




Final Cluster Assignments



Final Cluster Assignments




Final Cluster Assignments




Results on EMG_example_1_90s_fs_2k.csv


Channel 1




Power Spectrum of Mean Centered Signal




Power Spectrum of Mean Centered FILTERED Signal




Filtered EMG Signal




Spike Detected EMG Signal




Spike Detected EMG Signal




3-D Embedding t-SNE for Spikes





PCA Dimensionality Reduction of Spikes





Sorted Spikes in Cluster 1




Results on EMG_example_20s_2000Hz-2016.csv







Spike Detected EMG Signal




Spike Detected EMG Signal



Spike Detected w/ Buffer Region and Cubic Spline Interpolation EMG Signal



3-D Embedding t-SNE for Spikes



PCA Dimensionality Reduction of Spikes

